

SECTION : 8A

SEAT BELTS

CAUTION : Disconnect the negative battery cable before removing or installing any electrical unit or when a tool or equipment could easily come in contact with exposed electrical terminals. Disconnecting this cable will help prevent personal injury and damage to the vehicle. The ignition must also be in LOCK unless otherwise noted.

TABLE OF CONTENTS

SPECIFICATIONS	8A-1	TWO-POINT LAP REAR CENTER SEAT BELT	8A-10
FASTENER TIGHTENING SPECIFICATIONS .	8A-1	CHILD SEAT TETHER ANCHOR	8A-11
SCHEMATIC AND WIRING DIAGRAMS	8A-2	GENERAL DESCRIPTION AND SYSTEM	
DRIVER SEAT BELT WARNING	8A-2	OPERATION	8A-12
DIAGNOSIS	8A-3	DRIVER SEAT BELT REMINDER	8A-12
DRIVER SEAT BELT WARNING	8A-3	PRETENSIONER FRONT SEAT BELT	8A-12
MAINTENANCE AND REPAIR	8A-6	THREE-POINT CLR SEAT BELT	8A-12
ON-VEHICLE SERVICE	8A-6	TWO-POINT LAP REAR CENTER SEAT BELT	8A-12
PRETENSIONER FRONT SEAT BELT	8A-6	12	
FRONT SEAT BELT HEIGHT ADJUSTER	8A-8	OPERATIONAL CHECKS	8A-12
THREE-POINT CLR SEAT BELT	8A-8	CHILD SEAT TETHER ANCHOR	8A-12


SPECIFICATIONS

FASTENER TIGHTENING SPECIFICATIONS

Application	N•m	Lb-Ft	Lb-In
Child Seat Tether Anchor Bolt	25	18	–
Front Seat Belt Height Adjuster Bolts	19	14	–
Seat Belt Anchor Bolt	35	26	–
Seat Belt Bracket Screws	3	–	27
Seat Belt Retractor Screw	10	–	89

SCHEMATIC AND WIRING DIAGRAMS

DRIVER SEAT BELT WARNING



DIAGNOSIS

DRIVER SEAT BELT WARNING

Seat Belt Warning Lamp Does Not Turn On at Any Time

Step	Action	Value(s)	Yes	No
1	1. Unbuckle the seat belt. 2. Close the doors of the vehicle. 3. Turn the ignition ON. Is the seat belt warning chime OK?		Go to <i>Step 13</i>	Go to <i>Step 2</i>
2	Check the seat belt warning fuse F18. Is fuse F18 blown?		Go to <i>Step 3</i>	Go to <i>Step 4</i>
3	1. Check for a short circuit and repair if necessary. 2. Replace the fuse. Is the repair complete?		System OK	
4	1. Turn the ignition ON. 2. Check the voltage at fuse F18. Is the voltage equal to the specified value?	11–14 v	Go to <i>Step 6</i>	Go to <i>Step 5</i>
5	Repair the open power supply circuit for fuse F18. Is the repair complete?		System OK	
6	1. Disconnect the seat belt switch connector (located under the driver's seat). 2. Connect a jumper between the terminals on the harness side of the seat belt switch connector. 3. Turn the ignition ON. Does the seat belt warning lamp turn on?		Go to <i>Step 7</i>	Go to <i>Step 8</i>
7	Replace the seat belt switch. Is the repair complete?		System OK	
8	1. Disconnect the chime module electrical connector. 2. Turn the ignition ON. 3. Check the voltage at the chime module connector, terminal 8. Is the voltage equal to the specified value?	11–14 v	Go to <i>Step 10</i>	Go to <i>Step 9</i>
9	Repair the open circuit between fuse F18 and the chime module. Is the repair complete?		System OK	
10	1. The chime module connector is disconnected. 2. Turn the ignition OFF. 3. Use an ohmmeter to measure resistance between ground and terminal 5 of the chime module. Is the resistance equal to the specified value?	$\approx 0 \Omega$	Go to <i>Step 12</i>	Go to <i>Step 11</i>
11	Repair the ground circuit for the chime module. Is the repair complete?		System OK	

8A – 4 SEAT BELTS

Step	Action	Value(s)	Yes	No
12	1. The chime module connector is disconnected. 2. Turn the ignition OFF. 3. Make sure the driver's seat belt is unbuckled. 4. Use an ohmmeter to measure resistance between ground and terminal 1 of the chime module. Is the resistance equal to the specified value?	$\approx 0 \Omega$	Go to <i>Step 14</i>	Go to <i>Step 13</i>
13	Repair the open circuit between ground and terminal 1 of the chime module connector. Is the repair complete?		System OK	
14	1. Remove the instrument cluster. 2. Check the seat belt warning lamp bulb. Is the bulb OK?		Go to <i>Step 16</i>	Go to <i>Step 15</i>
15	Replace the warning lamp bulb. Is the repair complete?		System OK	
16	1. If the seat belt switch and the chime module were disconnected in a previous step, make sure that they have been reconnected. 2. Leave the seat belt unbuckled. 3. Turn the ignition ON. 4. Check the voltage at terminal B8 of the instrument cluster. Is the voltage equal to the specified value?	11–14 v	Go to <i>Step 20</i>	Go to <i>Step 17</i>
17	1. Disconnect the chime module connector. 2. Use an ohmmeter to check for continuity between the chime module connector terminal 7 and the instrument cluster connector B8. Did the ohmmeter indicate the specified value?	$\approx 0 \Omega$	Go to <i>Step 19</i>	Go to <i>Step 18</i>
18	Repair the open circuit between the chime module terminal 7 and the instrument cluster terminal B8.		System OK	
19	Replace the chime module. Is the repair complete?		System OK	
20	Repair the open circuit between instrument cluster terminal B11 and ground. Is the repair complete?		System OK	

Seat Belt Warning Chime Does Not Work

Step	Action	Value(s)	Yes	No
1	1. Leave the seat belt unbuckled. 2. Close the doors of the vehicle. 3. Turn the ignition ON. Is the seat belt warning lamp ON?		Go to <i>Step 2</i>	Go to "Seat Belt Warning Lamp Does Not Turn On at Any Time"
2	1. Buckle the seat belt. 2. Open the driver's door and turn the headlamps on. 3. Turn the ignition ON. Does the chimework as a door-open or headlamps-on warning?		Go to <i>Step 3</i>	Go to <i>Step 4</i>
3	Replace the chime module. Is the repair complete?		System OK	
4	1. Disconnect the chime module electrical connector. 2. Use an ohmmeter to measure the resistance between ground and terminal 5 of the chime module connector. Is the resistance equal to the specified value?	$\approx 0 \Omega$	Go to <i>Step 3</i>	Go to <i>Step 5</i>
5	Repair the open circuit between ground and terminal 5 of the chimemodule connector. Is the repair complete?		System OK	




MAINTENANCE AND REPAIR


ON-VEHICLE SERVICE

PRETENSIONER FRONT SEAT BELT

Removal Procedure

1. Remove the plastic cap to reveal the lower B-pillar seat belt anchor.
2. Remove the bolt and the lower B-pillar seat belt anchor.
3. Remove the lower B-pillar trim panel. Refer to *Section 9G, InteriorTrim*.
4. Remove the plastic cap to reveal the upper B-pillar seat belt anchor.
5. Remove the bolt and the upper B-pillar seat belt anchor.
6. Remove the screws and the seat belt bracket.
7. Remove the screw and the seat belt retractor.





Installation Procedure

CAUTION : Failure to install the correct retractor screw can cause the pretensioner seat belt to malfunction in an accident, possibly resulting in personal injury.

Notice : Dissimilar metals in direct contact with each other may corrode rapidly. Make sure to use the correct fasteners to prevent premature corrosion.

1. Install the seat belt retractor with the screw.

Tighten

Tighten the seat belt retractor screw to 10 N•m (89 lbin).

2. Install the seat belt bracket with the screws.

Tighten



Tighten the seat belt bracket screws to 3 N•m (27 lb-in).

3. Install the upper B-pillar seat belt anchor with the bolt.

Tighten

Tighten the seat belt anchor bolt to 35 N•m (26 lb-ft).

4. Install the seat belt anchor plastic cap.




5. Install the lower B-pillar trim panel. Refer to Section 9G, Interior Trim.

6. Install the lower B-pillar seat belt anchor with the bolt.

Tighten

Tighten the seat belt anchor bolt to 38 N•m (28 lb-ft).


7. Install the seat belt anchor plastic cap.



FRONT SEAT BELT HEIGHT ADJUSTER

Removal Procedure

1. Remove the upper B-pillar trim panel. Refer to *Section 9G, Interior Trim*.
2. Remove the bolts and the seat belt height adjuster.



Installation Procedure


Notice : Dissimilar metals in direct contact with each other may corrode rapidly. Make sure to use the correct fasteners to prevent premature corrosion.

1. Install the seat belt height adjuster with the bolts.

Tighten

Tighten the front seat belt height adjuster bolts to 19 N•m (14 lb–ft).


2. Install the upper B-pillar trim panel. Refer to *Section 9G, Interior Trim*.




THREE-POINT CLR SEAT BELT

Removal Procedure


1. Remove the deck lid sill plate cover and the luggage compartment wheelhouse trim panel. Refer to *Section 9G, Interior Trim*.
2. Remove the bolt and the luggage compartment seat belt anchor.



3. Remove the bolt and the C-pillar seat belt anchor.



4. Remove the bolt and the floor seat belt anchor.
5. Remove the seat belt.




Installation Procedure

Notice : Dissimilar metals in direct contact with each other may corrode rapidly. Make sure to use the correct fasteners to prevent premature corrosion.

1. Install the luggage compartment seat belt anchor with the bolt.

Tighten


Tighten the seat belt anchor bolt to 35 N•m (26 lb–ft).




2. Feed the free end of the seat belt from the luggage compartment through the deck lid sill plate.
3. Install the floor seat belt anchor with the bolt.

Tighten

Tighten the seat belt anchor bolt to 38 N•m (28 lb–ft).




4. Install the C-pillar seat belt anchor with the bolt.
- ### **Tighten**
- Tighten the seat belt anchor bolt to 35 N•m (26 lb–ft).
5. Install the deck lid sill plate cover and the luggage compartment wheelhouse trim panel. Refer to *Section 9G, Interior Trim*.



TWO-POINT LAP REAR CENTER SEAT BELT

Removal Procedure

1. Remove the rear seat cushion. Refer to *Section 9H, Seats*.
2. Remove the bolts and the seat belt anchors.



Installation Procedure

Notice : Dissimilar metals in direct contact with each other may corrode rapidly. Make sure to use the correct fasteners to prevent premature corrosion.

1. Install the seat belt anchors with the bolts.

Tighten


Tighten the seat belt anchor bolts to 35 N•m (26 lb–ft).

2. Install the rear seat cushion. Refer to *Section 9H, Seats*.

CHILD SEAT TETHER ANCHOR

Removal Procedure

1. Open the tether anchor access cap.
2. Remove the bolt and the tether anchor.



Installation Procedure


Notice : Dissimilar metals in direct contact with each other may corrode rapidly. Make sure to use the correct fasteners to prevent premature corrosion.

1. Install the tether anchor with the bolt.

Tighten

Tighten the child seat tether anchor bolt to 25 N•m (18 lb–ft).

2. Close the tether anchor access cap.



GENERAL DESCRIPTION AND SYSTEM OPERATION

DRIVER SEAT BELT REMINDER

The driver's safety belt incorporates a safety belt reminder light in the I/P cluster to remind the driver if the safety belt is not fastened when the the ignition is turned ON.

PRETENSIONER FRONT SEAT BELT

The pretensioner front seat belt is standard. It contains a mechanically controlled pyrotechnical retractor which reduces the seat belt slack when it is activated in a head-on or angled front collision. The pretensioner front seat belt must be replaced after an accident that causes its activation.

THREE-POINT CLR SEAT BELT

Three-point convertible locking retractor (CLR) seat belts are standard for the front seat passenger and the rear seat outboard passenger positions.

The CLR seat belt has the following two operational modes:

- Emergency-locking retractor (ELR) mode.
- Auto-locking retractor (ALR) mode.

Normally, the seat belt operates in the ELR mode. This allows the passenger freedom of movement, except in emergency situations.

However, when the belt is fully extended and released, the seat belt operates in the ALR mode. The ALR mode does not allow movement. It is designed to hold a child seat firmly to the seat of the vehicle.

To return the seat belt to the ELR mode, allow the seat belt to retract fully.

TWO-POINT LAP REAR CENTER SEAT BELT

The two-point lap rear center seat belt is a single continuous length of webbing. The webbing is routed from the anchor through a latch plate and into a single retractor.

OPERATIONAL CHECKS

- Keep sharp objects and potentially damaging objects away from the seat belts.
 - Avoid bending or damaging any portion of the buckle or the latch plate.
 - Do not bleach or dye the belt webbing. Use only mild soap and water in order to clean the belts.
 - When installing the seat belt anchor bolts and the screws, start the bolts and the screws by hand in order to prevent cross-threading.
 - Do not attempt any repairs on the retractor mechanisms or the covers. Replace any defective assemblies with new assemblies.
 - Replace any belts that are cut or damaged in any way.
1. Inspect all seat belt anchor bolts and the screws in order to verify that they are secure.
 2. Inspect the seat belt buckle. The buckle must lock and unlock easily.
 3. After inserting the latch into the buckle, tug sharply on the belt. The buckle must remain locked.
 4. Fully extend the shoulder belt portion to make sure that there is no twisting or tears in the belt.
 5. Let the shoulder belt retract fully. The belt should retract easily.

CHILD SEAT TETHER ANCHOR

There are three child seat tether anchors on the rear deck lid sill plate. There is one anchor for each rear seat position.