

SECTION : 4F

ANTILOCK BRAKE SYSTEM AND TRACTION CONTROL SYSTEM

CAUTION : *Disconnect the negative battery cable before removing or installing any electrical unit or when a tool or equipment could easily come in contact with exposed electrical terminals. Disconnecting this cable will help prevent personal injury and damage to the vehicle. The ignition must also be in LOCK unless otherwise noted.*

TABLE OF CONTENTS

SPECIFICATIONS	4F-2	DTC 31 RIGHT REAR WHEEL SPEED SENSOR FAULT	4F-37
FASTENER TIGHTENING SPECIFICATIONS .	4F-2	DTC 33 RIGHT REAR WHEEL SPEED SENSOR CONTINUITY FAULT	4F-40
SPECIAL TOOLS	4F-2	DTC 35 LEFT REAR WHEEL SPEED SENSOR FAULT	4F-42
SPECIAL TOOLS TABLE	4F-2	DTC 37 LEFT REAR WHEEL SPEED SENSOR CONTINUITY FAULT	4F-45
SCHEMATIC AND ROUTING DIAGRAMS	4F-3	DTC 41/42 RIGHT FRONT INLET AND OUTLET VALVE SOLENOID FAULT	4F-47
ABS CIRCUIT (1 of 2)	4F-3	DTC 43/44 RIGHT FRONT PRIME LINE AND TRACTION CONTROL SYSTEM (TCS) PILOT VALVE FAULT	4F-49
ABS CIRCUIT (2 of 2)	4F-4	DTC 45/46 LEFT FRONT INLET AND OUTLET VALVE SOLENOID FAULT	4F-51
EBCM CONNECTOR FACE VIEW	4F-5	DTC 47/48 LEFT FRONT PRIME LINE AND TRACTION CONTROL SYSTEM (TCS) PILOT VALVE FAULT	4F-53
EBCM CONNECTOR FACE VIEW	4F-6	DTC 50 STOPLAMP SWITCH FAULT	4F-55
COMPONENT LOCATOR	4F-7	DTC 51/52 RIGHT REAR INLET AND OUTLET VALVE SOLENOID FAULT	4F-58
ABS AND TCS SYSTEM	4F-7	DTC 55/56 LEFT REAR INLET AND OUTLET VALVE SOLENOID FAULT	4F-60
DIAGNOSIS	4F-8	DTC 61 PUMP MOTOR OR PUMP MOTOR RELAY FAULT	4F-62
DIAGNOSTIC CIRCUIT CHECK	4F-8	DTC 63 VALVE RELAY CIRCUIT FAULT	4F-64
ABS INDICATOR LAMP INOPERATIVE	4F-11	DTC 65 PUMP FAULT LONG TERM (TCS ONLY)	4F-66
POWER SUPPLY TO CONTROL MODULE, NO DTCS STORED	4F-14	DTC 71 ABS CONTROL MODULE INTERNAL FAULT	4F-67
ABS INDICATOR LAMP ILLUMINATED CONTINUOUSLY, NO DTCS STORED	4F-17	DTC 85 LOW VOLTAGE FAULT	4F-69
TRACTION CONTROL SYSTEM INDICATOR LAMP INOPERATIVE	4F-19	MAINTENANCE AND REPAIR	4F-72
SELF-DIAGNOSTICS	4F-22	ON-VEHICLE SERVICE	4F-72
DISPLAYING DTCS	4F-22	SERVICE PRECAUTIONS	4F-72
CLEARING DTCS	4F-22	BLEEDING SYSTEM	4F-73
INTERMITTENTS AND POOR CONNECTIONS	4F-22	ABS 5.3 ASSEMBLY	4F-73
DTC 21 RIGHT FRONT WHEEL SPEED SENSOR FAULT	4F-23	FRONT WHEEL SPEED SENSOR	4F-74
DTC 23 RIGHT FRONT WHEEL SPEED SENSOR CONTINUITY FAULT	4F-26		
DTC 25 LEFT FRONT WHEEL SPEED SENSOR FAULT	4F-28		
DTC 27 LEFT FRONT WHEEL SPEED SENSOR CONTINUITY FAULT	4F-31		
DTC 28 WHEEL SPEED SENSOR FREQUENCY ERROR	4F-33		

4F – 2 ANTILOCK BRAKE SYSTEM AND TRACTION CONTROL SYSTEM

FRONT WHEEL SPEED SENSOR JUMPER HARNESS	4F-75	ANTILOCK BRAKING MODE	4F-84
REAR WHEEL SPEED SENSOR	4F-77	TRACTION CONTROL MODE	4F-86
REAR WHEEL SPEED SENSOR JUMPER HARNESS	4F-78	TIRES AND ABS/TCS	4F-88
SYSTEM FUSE	4F-80	ELECTRONIC BRAKE CONTROL MODULE (EBCM)	4F-88
INDICATORS	4F-80	FRONT WHEEL SPEED SENSORS	4F-89
GENERAL DESCRIPTION AND SYSTEM		FRONT WHEEL SPEED SENSOR RINGS ...	4F-89
OPERATION	4F-81	REAR WHEEL SPEED SENSORS AND RINGS	4F-89
BASIC KNOWLEDGE REQUIRED	4F-81	VALVE RELAY AND PUMP MOTOR RELAY .	4F-89
ABS SYSTEM COMPONENTS	4F-81	WIRING HARNESS	4F-89
BASE BRAKING MODE	4F-83	INDICATORS	4F-89


SPECIFICATIONS

FASTENER TIGHTENING SPECIFICATIONS


Application	N•m	Lb-Ft	Lb-In
ABS 5.3 Mounting NutsEBCM Connector	9	–	80
Brake Pipe Nuts	12	–	106
Front Wheel Speed Sensor Bolt	8	–	71
Rear Wheel Speed Sensor Bolt	8	–	71

SPECIAL TOOLS

SPECIAL TOOLS TABLE


 <p>A410B026</p>	Scanner 100
---	-------------

ABS CIRCUIT (2 of 2)



EBCM CONNECTOR FACE VIEW (WITHOUT TRACTION CONTROL SYSTEM)

EBCM Connector




C107F035

Pin	Color	Circuit
1	DK BLU	Right Rear Ground
2	–	Not Used
3	BRN	Right Rear Sensor
4	PPL	Right Front Ground
5	YEL	Right Front Sensor
6	WHT	Left Front Ground
7	ORN	Left Front Sensor
8	DK BLU	Left Rear Ground
9	BRN	Left Rear Ground
10	–	Not Used
11	DK BLU/ WHT	Serial Data Link
12	–	Not Used
13	–	Not Used

14	LT BLU	Brake Light Switch
15	Ignition	Ignition
16	BLK	Motor Ground
17	RED	Battery
18	RED	Battery
19	BLK	Instrument Ground
20	–	Not Used
21	DK GRN/ BLK	ABS Warning Lamp
22	–	Not Used
23	–	Not Used
24	–	Not Used
25	–	Not Used
26	–	Not Used
SB	–	Shorting Bar

EBCM CONNECTOR FACE VIEW (WITH TRACTION CONTROL SYSTEM)

EBCM Connector




C107F036

Pin	Color	Circuit
1	DK BLU	Right Rear Ground
2	–	Not Used
3	BRN	Right Rear Sensor
4	PPL	Right Front Ground
5	YEL	Right Front Sensor
6	WHT	Left Front Ground
7	ORN	Left Front Sensor
8	DK BLU	Left Rear Ground
9	BRN	Left Rear Ground
10	–	Not Used
11	DK BLU/ WHT	Serial Data Link
12	–	Not Used
13	–	Not Used
14	LT BLU	Brake Light Switch
15	PNK	Ignition

16	BLK	Ignition
17	RED	Battery
18	RED	Battery
19	BLK	Instrument Ground
20	–	Not Used
21	DK GRN/ BLK	ABS Warning Lamp
22	–	Not Used
23	–	Not Used
24	–	Not Used
25	–	Not Used
26	–	Not Used
27	–	Not Used
28	DK GRN	TCS Warning Lamp
29	–	Not Used
30	–	Not Used
31	–	Not Used
SB	–	Shorting Bar

COMPONENT LOCATOR

ABS AND TCS SYSTEM



C107F025

- | | |
|---|--|
| 1. Right Front Wheel Speed Sensor | 12. Left Rear Wheel Speed Sensor Connector |
| 2. Brake Master Cylinder | 13. Body Wiring Harness |
| 3. Master Cylinder Reservoir | 14. Connector C206 |
| 4. Grommet | 15. Connectors C202, C205 |
| 5. Right Front Wheel Speed Sensor Connector | 16. EBCM Connector J1 |
| 6. Brake Fluid Level Switch Connector | 17. Left Front Speed Sensor Connector |
| 7. Instrument Cluster | 18. Grommet |
| 8. Grommet | 19. Hydraulic Modulator with Attached EBCM |
| 9. Right Rear Wheel Speed Sensor Connector | 20. Connector C107 |
| 10. Right Rear Wheel Speed Sensor | 21. Left Front Wheel Speed Sensor |
| 11. Left Rear Wheel Speed Sensor | |