



SCHEMATIC AND ROUTING DIAGRAMS


ECM WIRING DIAGRAM (2.2L DOHC - 1 OF 6)









ECM WIRING DIAGRAM (2.2L DOHC - 2 OF 6)















ECM WIRING DIAGRAM (2.2L DOHC – 3 OF 6)








CONNECTOR END VIEW










COMPONENT LOCATOR

COMPONENT LOCATOR



Components on ECM Harness

11. Engine Control Module (ECM)
12. Data Link Connector (DLC)
13. Malfunction Indicator Lamp (MIL)
14. ECM/ABS Harness Ground
15. Fuse Panel (2)

ECM Controlled Devices

20. Exhaust Gas Recirculation (EGR) Valve
21. Fuel Injector (4)
22. Idle Air Control (IAC) Valve
23. Fuel Pump Relay
24. Engine Fan Relays
25. Series/Parallel Cooling Fan Relay
26. Electronic Ignition (EI) System Ignition Coil
27. Evaporative Emission Canister Purge Solenoid
28. Ignition 1 Relay
29. A/C Compressor Relay

Information Sensors

30. Manifold Absolute Pressure (MAP) Sensor
31. Pre-Converter (O2S 1) Oxygen Sensor
32. Throttle Position (TP) Sensor
33. Engine Coolant Temperature (ECT) Sensor
34. Intake Air Temperature (IAT) Sensor
35. Vehicle Speed Sensor (VSS)
36. P/N Position Switch (Automatic Transaxle only)
37. Crankshaft Position (CKP) Sensor
38. Knock Sensor
40. Post-Converter Oxygen (HO2S 2) Sensor
41. Camshaft Position (CMP) Sensor

Not ECM Connected

42. Evaporative Emission Canister (under vehicle, behind right rear wheel)
43. Oil Pressure Switch
44. Air Cleaner
45. Fuel Cutoff Switch
46. G Sensor