

SECTION : 1F

ENGINE CONTROLS

CAUTION : *Disconnect the negative battery cable before removing or installing any electrical unit or when a tool or equipment could easily come in contact with exposed electrical terminals. Disconnecting this cable will help prevent personal injury and damage to the vehicle. The ignition must also be in LOCK unless otherwise noted.*

TABLE OF CONTENTS

SPECIFICATIONS	1F-4	FUEL PUMP RELAY CIRCUIT CHECK	1F-54
ENGINE DATA DISPLAY TABLES	1F-4	IGNITION 1 RELAY CIRCUIT CHECK	1F-57
ENGINE DATA DISPLAY TABLE DEFINITIONS	1F-13	MANIFOLD ABSOLUTE PRESSURE CHECK	1F-59
FASTENER TIGHTENING SPECIFICATIONS	1F-16	PARK/NEUTRAL POSITION SWITCH	1F-61
FUEL SYSTEM SPECIFICATIONS	1F-17	IDLE AIR CONTROL SYSTEM CHECK	1F-63
TEMPERATURE VS RESISTANCE	1F-17	IGNITION SYSTEM CHECK	1F-66
SCHEMATIC AND ROUTING DIAGRAMS	1F-18	ENGINE COOLING FAN CIRCUIT CHECK ..	1F-70
ECM WIRING DIAGRAM (2.2L DOHC – 1 OF 6)	1F-18	DATA LINK CONNECTOR DIAGNOSIS	1F-77
8		FUEL INJECTOR BALANCE TEST	1F-80
ECM WIRING DIAGRAM (2.2L DOHC – 2 OF 6)	1F-19	EVAP CONTROL SYSTEM DIAGNOSIS	1F-81
9		TROUBLE CODE DIAGNOSIS	1F-84
ECM WIRING DIAGRAM (2.2L DOHC – 3 OF 6)	1F-20	CLEARING TROUBLE CODES	1F-84
0		DIAGNOSTIC TROUBLE CODES	1F-84
ECM WIRING DIAGRAM (2.2L DOHC – 4 OF 6)	1F-21	DTC P0106 MANIFOLD ABSOLUTE PRESSURE	
1		RATIONALITY	1F-87
ECM WIRING DIAGRAM (2.2L DOHC – 5 OF 6)	1F-22	DTC P0107 MANIFOLD ABSOLUTE PRESSURE	
2		LOW VOLTAGE	1F-89
ECM WIRING DIAGRAM (2.2L DOHC – 6 OF 6)	1F-23	DTC P0108 MANIFOLD ABSOLUTE PRESSURE	
3		HIGH VOLTAGE	1F-92
CONNECTOR END VIEW	1F-24	DTC P0112 INTAKE AIR TEMPERATURE LOW	
COMPONENT LOCATOR	1F-28	VOLTAGE	1F-95
COMPONENT LOCATOR	1F-28	DTC P0113 INTAKE AIR TEMPERATURE HIGH	
DIAGNOSIS	1F-30	VOLTAGE	1F-98
SYSTEM DIAGNOSIS	1F-30	DTC P0117 ENGINE COOLANT TEMPERATURE	
DIAGNOSTIC AIDS	1F-30	LOW VOLTAGE	1F-100
IDLE LEARN PROCEDURE	1F-30	DTC P0118 ENGINE COOLANT TEMPERATURE	
ON-BOARD DIAGNOSTIC (OBD II) SYSTEM		HIGH VOLTAGE	1F-102
CHECK	1F-31	DTC P0121 THROTTLE POSITION SENSOR	
ECM OUTPUT DIAGNOSIS	1F-33	RATIONALITY	1F-105
MULTIPLE ECM INFORMATION SENSOR DTCS		DTC P0122 THROTTLE POSITION SENSOR LOW	
SET	1F-35	VOLTAGE	1F-108
ENGINE CRANKS BUT WILL NOT RUN	1F-39	DTC P0123 THROTTLE POSITION SENSOR HIGH	
NO MALFUNCTION INDICATOR LAMP	1F-46	VOLTAGE	1F-111
MALFUNCTION INDICATOR LAMP ON STEADY	1F-49	DTC P0125 ENGINE COOLANT TEMPERATURE	
49		INSUFFICIENT FOR CLOSED LOOP FUEL	
FUEL SYSTEM DIAGNOSIS	1F-51	CONTROL	1F-114
		DTC P0131 O2 BANK 1 SENSOR 1 LOW VOLTAGE	
		1F-117	

1F – 2 ENGINE CONTROLS

DTC P0132 O2 BANK 1 SENSOR 1 HIGH VOLTAGE 1F-120	DTC P0420 CATALYST BANK 1 LOW EFFICIENCY 1 F-221
DTC P0133 O2 BANK 1 SENSOR 1 SLOW RESPONSE 1F-123	DTC P0440 EVAPORATIVE EMISSION SYSTEM LARGE LEAK/LOW TANK VACUUM 1F-223
DTC P0134 O2 BANK 1 SENSOR 1 NO ACTIVITY 1F -127	DTC P0442 EVAPORATIVE EMISSION SYSTEM SMALL LEAK 1F-228
DTC P0137 HO2 BANK 1 SENSOR 2 LOW VOLTAGE 1F-130	DTC P0443 EVAPORATIVE EMISSION SYSTEM PURGE CONTROL CIRCUIT 1F-232
DTC P0138 HO2 BANK 1 SENSOR 2 HIGH VOLTAGE 1F-133	DTC P0446 EVAPORATIVE EMISSION SYSTEM VENT CONTROL MALFUNCTION 1F-235
DTC P0140 HO2 BANK 1 SENSOR 2 NO ACTIVITY 1 F-137	DTC P0449 EVAPORATIVE EMISSION SYSTEM VENT SOLENOID CIRCUIT FAULT 1F-238
DTC P0141 HO2 BANK 1 SENSOR 2 HEATER 1F-1 40	DTC P0452 FUEL TANK PRESSURE SENSOR LOW VOLTAGE 1F-241
DTC P0171 BANK 1 SYSTEM TOO LEAN .. 1F-143	DTC P0453 FUEL TANK PRESSURE SENSOR HIGH VOLTAGE 1F-244
DTC P0172 BANK 1 SYSTEM TOO RICH .. 1F-147	DTC P0461 FUEL LEVEL STUCK 1F-247
DTC P0201 INJECTOR 1 CIRCUIT FAULT . 1F-151	DTC P0462 FUEL LEVEL LOW VOLTAGE .. 1F-250
DTC P0202 INJECTOR 2 CIRCUIT FAULT . 1F-154	DTC P0463 FUEL LEVEL HIGH VOLTAGE . 1F-253
DTC P0203 INJECTOR 3 CIRCUIT FAULT . 1F-157	DTC P0480 LOW SPEED COOLING FAN CONTROL CIRCUIT FAULT 1F-256
DTC P0204 INJECTOR 4 CIRCUIT FAULT . 1F-160	DTC P0481 HIGH SPEED COOLING FAN CONTROL CIRCUIT FAULT 1F-259
DTC P0300 MULTIPLE CYLINDER MISFIRE 1F-163	DTC P0502 VEHICLE SPEED SENSOR (ENGINE SIDE) NO SIGNAL 1F-262
DTC P0301 CYLINDER 1 MISFIRE 1F-168	DTC P0506 IDLE SPEED RPM LOWER THAN DESIRED IDLE SPEED 1F-265
DTC P0302 CYLINDER 2 MISFIRE 1F-172	DTC P0507 IDLE SPEED RPM HIGHER THAN DESIRED IDLE SPEED 1F-268
DTC P0303 CYLINDER 3 MISFIRE 1F-176	DTC P0532 A/C PRESSURE SENSOR LOW 1F-271
DTC P0304 CYLINDER 4 MISFIRE 1F-180	DTC P0533 A/C PRESSURE SENSOR HIGH 1F-274
DTC P0325 KNOCK SENSOR DSNEF INTERNAL MALFUNCTION 1F-184	DTC P0562 SYSTEM VOLTAGE (ENGINE SIDE) TOO LOW 1F-277
DTC P0327 KNOCK SENSOR CIRCUIT FAULT 1F-1 86	DTC P0563 SYSTEM VOLTAGE (ENGINE SIDE) TOO HIGH 1F-279
DTC P0336 58X CRANK POSITION EXTRA/ MISSING PULSES 1F-189	DTC P0601 ECM (ENGINE SIDE) CHECKSUM FAULT 1F-281
DTC P0337 58X CRANK POSITION NO SIGNAL 1F- 191	DTC P1106 MANIFOLD ABSOLUTE PRESSURE INTERMITTENT HIGH VOLTAGE 1F-282
DTC P0341 CAMSHAFT POSITION SENSOR RATIONALITY 1F-194	DTC P1107 MANIFOLD ABSOLUTE PRESSURE INTERMITTENT LOW VOLTAGE 1F-284
DTC P0342 CAMSHAFT POSITION SENSOR NO SIGNAL 1F-197	DTC P1111 INTAKE AIR TEMPERATURE INTERMITTENT HIGH VOLTAGE 1F-286
DTC P0351 IGNITION CONTROL CIRCUIT A FAULT 1F-200	DTC P1112 INTAKE AIR TEMPERATURE INTERMITTENT LOW VOLTAGE 1F-289
DTC P0352 IGNITION CONTROL CIRCUIT B FAULT 1F-202	DTC P1114 ENGINE COOLANT TEMPERATURE INTERMITTENT LOW VOLTAGE 1F-291
DTC P0401 EXHAUST GAS RECIRCULATION INSUFFICIENT FLOW 1F-204	DTC P1115 ENGINE COOLANT TEMPERATURE INTERMITTENT HIGH VOLTAGE 1F-293
DTC P0402 EXHAUST GAS RECIRCULATION EXCESSIVE FLOW 1F-206	DTC P1121 THROTTLE POSITION SENSOR INTERMITTENT HIGH VOLTAGE 1F-296
DTC P0404 EXHAUST GAS RECIRCULATION OPEN VALVE POSITION ERROR 1F-210	DTC P1122 THROTTLE POSITION SENSOR INTERMITTENT LOW VOLTAGE 1F-298
DTC P0405 EXHAUST GAS RECIRCULATION PINTLE POSITION LOW VOLTAGE 1F-214	
DTC P0406 EXHAUST GAS RECIRCULATION PINTLE POSITION HIGH VOLTAGE 1F-217	

DTC P1133 O2 BANK 1 SENSOR 1 TOO FEW TRANSITIONS	1F-300	DIESELING, RUN-ON	1F-367
DTC P1134 O2 BANK 1 SENSOR 1 TRANSITION RATIO	1F-304	BACKFIRE	1F-368
DTC P1171 FUEL SUPPLY SYSTEM LEAN DURING POWER ENRICHMENT	1F-307	MAINTENANCE AND REPAIR	1F-369
DTC P1336 58X CRANK POSITION TOOTH ERROR NOT LEARNED	1F-309	ON-VEHICLE SERVICE	1F-369
DTC P1391 G SENSOR ROUGH ROAD RATIONALITY	1F-311	FUEL TANK	1F-369
DTC P1392 G SENSOR ROUGH ROAD LOW VOLTAGE	1F-314	FUEL PUMP	1F-371
DTC P1393 G SENSOR ROUGH ROAD HIGH VOLTAGE	1F-317	FUEL TANK PRESSURE SENSOR	1F-372
DTC P1404 EXHAUST GAS RECIRCULATION CLOSED VALVE PINTLE ERROR	1F-320	FUEL FILTER	1F-373
DTC P1441 EVAPORATIVE EMISSION CONTINUOUS PURGE FLOW	1F-324	FUEL RAIL AND INJECTORS	1F-374
DTC P1508 IDLE AIR CONTROL COUNTS TOO LOW	1F-327	FUEL PRESSURE REGULATOR	1F-376
DTC P1509 IDLE AIR CONTROL COUNTS TOO HIGH	1F-330	ENGINE COOLANT TEMPERATURE SENSOR 1F-378	
DTC P1520 PARK/NEUTRAL DISCRETE FAULT 1F-333		THROTTLE POSITION SENSOR	1F-378
DTC P1546 A/C CLUTCH OUTPUT CIRCUIT FAULT 1F-335		THROTTLE BODY	1F-379
DTC P1618 ECM INTERNAL SPI COMMUNICATION	1F-338	OXYGEN SENSOR (O2S 1)	1F-381
DTC P1625 ECM INTERNAL SYSTEM RESET 1F-339		HEATED OXYGEN SENSOR (HO2S 2)	1F-382
DTC P1627 ECM A/D CONVERSION ERROR 1F-341		INTAKE AIR TEMPERATURE SENSOR	1F-383
DTC P1635 ECM 5 VOLT REFERENCE LINE LOW 1F-342		IDLE AIR CONTROL VALVE	1F-383
DTC P1640 ODM INTERNAL SPI COMMUNICATION	1F-345	MANIFOLD ABSOLUTE PRESSURE SENSOR 1F-384	
SYMPTOM DIAGNOSIS	1F-348	EXHAUST GAS RECIRCULATION VALVE ..	1F-386
IMPORTANT PRELIMINARY CHECKS	1F-348	KNOCK SENSOR	1F-386
INTERMITTENTS	1F-348	G SENSOR	1F-388
HARD START	1F-350	EVAPORATIVE EMISSION CANISTER	1F-388
SURGES OR CHUGGLES	1F-352	EVAPORATIVE EMISSION CANISTER PURGE SOLENOID	1F-389
LACK OF POWER, SLUGGISHNESS, OR SPONGINESS	1F-354	CRANKSHAFT POSITION SENSOR	1F-390
DETONATION/SPARK KNOCK	1F-355	CAMSHAFT POSITION SENSOR	1F-391
HESITATION, SAG, STUMBLE	1F-357	ENGINE CONTROL MODULE	1F-392
CUTS OUT, MISSES	1F-358	ELECTRONIC IGNITION SYSTEM IGNITION COIL 1F-393	
POOR FUEL ECONOMY	1F-361	FUEL CUTOFF SWITCH	1F-394
ROUGH, UNSTABLE, OR INCORRECT IDLE, STALLING	1F-362	GENERAL DESCRIPTION AND SYSTEM OPERATION	1F-395
EXCESSIVE EXHAUST EMISSIONS OR ODORS 1F-365		IGNITION SYSTEM OPERATION	1F-395
		ELECTRONIC IGNITION SYSTEM IGNITION COIL 1F-395	
		CRANKSHAFT POSITION SENSOR	1F-395
		CAMSHAFT POSITION SENSOR	1F-395
		IDLE AIR SYSTEM OPERATION	1F-395
		FUEL CONTROL SYSTEM OPERATION ...	1F-395
		EVAPORATIVE EMISSION CONTROL SYSTEM OPERATION	1F-396
		EVAPORATIVE EMISSION CANISTER	1F-396
		ON BOARD REFUELING VAPOR RECOVERY (ORVR) SYSTEM	1F-397
		POSITIVE CRANKCASE VENTILATION CONTROL SYSTEM OPERATION	1F-397
		ENGINE COOLANT TEMPERATURE SENSOR 1F-397	

1F – 4 ENGINE CONTROLS

THROTTLE POSITION SENSOR	1F-397	G SENSOR	1F-400
CATALYST MONITOR OXYGEN SENSORS	1F-398	STRATEGY-BASED DIAGNOSTICS	1F-400
EXHAUST GAS RECIRCULATION VALVE . .	1F-398	OBD II SERVICEABILITY ISSUES	1F-401
INTAKE AIR TEMPERATURE SENSOR	1F-398	SERIAL DATA COMMUNICATIONS	1F-402
IDLE AIR CONTROL VALVE	1F-398	ON-BOARD DIAGNOSTIC (OBD II)	1F-402
MANIFOLD ABSOLUTE PRESSURE SENSOR	1F-399	COMPREHENSIVE COMPONENT MONITOR	
9		DIAGNOSTIC OPERATION	1F-402
ENGINE CONTROL MODULE	1F-399	COMMON OBD TERMS	1F-403
FUEL INJECTOR	1F-400	DTC TYPES	1F-404
FUEL CUTOFF SWITCH	1F-400	READING DIAGNOSTIC TROUBLE CODES	1F-405
KNOCK SENSOR	1F-400	PRIMARY SYSTEM-BASED DIAGNOSTICS	1F-407

SPECIFICATIONS

ENGINE DATA DISPLAY TABLES

Engine Data Display 01 Selected by 2: Data Display 1: Engine Data 2.2L Manual Transmission

Parameter	Scaling	Value
Engine Speed	$\text{rpm}=\text{N}/4$	± 100 rpm from the Desired rpm
Desired Idle	$\text{rpm}=\text{N} \times 12.5$	ECM Idle Command
Engine Coolant Temperature	$\text{Celsius}=\text{n}-40$	$85^{\circ}-115^{\circ}\text{F}$ ($185^{\circ}-239^{\circ}\text{C}$)
Intake Air Temperature	$\text{Celsius}=\text{n}-40$	$10^{\circ}-80^{\circ}\text{F}$ ($50^{\circ}-176^{\circ}\text{C}$)
Throttle Position	$\%=\text{n}/2.56$	0% (up to 100% at wide open throttle)
Throttle Position	$\text{Volts}=\text{n}/51$	0.200-0.900v (up to 5.0 at wide open throttle)
MAP	$\text{kPa}=\text{N}$	12-103 kPa
BARO	$\text{kPa}=(\text{n}+28)/2.71$	65-100 kPa (varies with altitude and with the BARO pressure)
EGR Actual Position	$\%=\text{n}/2.56$	0%
EGR Desired Position	$\%=\text{n}/2.56$	
EGR Feedback	$\text{Volt}=\text{5n}/255$	0-5 volts
IAC Position	$\text{Counts}=\text{N}$	5-60
Cam Speed Activity	$\text{Counts}=\text{N}$	0-255
Ignition Voltage	$\text{Volts}=\text{n}/10$	12.0-15.0
Engine Run Time	$\text{Seconds}=\text{N}$	00:00:00-18:12:15 (hours:minutes:seconds)
BPW Bank 1	$\text{ms}=\text{N}/65.535$	0-999.9 ms
Air Fuel Ratio	$\text{x}:1=\text{n}/10$	0:1-25.5:1
Spark	$\text{Degrees}=(\text{n}/2)-64$	64 to -64
Knock Retard	$\text{Degrees}=\text{N}/(256/22.5)$	0-90
Knock Active Counter	$\text{Counts}=\text{N}$	0-255
Knock Present	1=Yes/0=No	-
Calculated Load	$\%=\text{N}/2.56$	0-100
Vehicle Speed	$\text{mph}=\text{n}/1.61$	0-255 mph

Parameter	Scaling	Value
Air Condition Pressure	Volt=5n/255	0–5 volts
O2 Sensor Bank 1 Sensor 1	mV=N/0.2304	0–1132 mV
O2 Sensor Bank 1 Sensor 2	mV=N/0.2304	0–1132 mV
Decel Fuel Mode	1=Yes/0=No	–
Power Enrichment Mode	1=Yes/0=No	–
Closed Loop	1=Yes/0=No	–
Loop Status	See Table 3	
Hot Loop Open	1=Yes/0=No	–
Rich/Lean Bank 1	1=Rich/0=Lean	–
Short Term Fuel Trim	%=(N–128)/1.28	–100 to 100%
Long Term Fuel Trim	%=(N–128)/1.28	–100 to 100%
EVAP Purge Solenoid	%=N/2.56	0–100%
EVAP Vent Solenoid	1=On/0=Off	–
IAC Base Position	Counts=N	0–255
Fuel Trim Cell	Cell=N	
Calculated Air Flow	g/sec=N/128	0–512 g/sec
Weak Cylinder	See Table 01	–
Rough Road Sensor	Volt=5n/255	
5 Volt Reference	Volt=5n/255	
Throttle at Idle	1=Yes/0=No	–
Power Steering Cramp	1=Yes/0=No	–
Air Conditioning Request	1=On/0=Off	–
Air Conditioning Clutch	1=On/0=Off	–
Fuel Pump	1=On/0=Off	–
Malfunction Indicator Lamp	1=On/0=Off	–
Upshift Lamp	1=On/0=Off	–
Low Fuel Lamp	1=On/0=Off	–
Hot Open Loop Lamp	1=On/0=Off	–
Variable Gate Intake	1=Long/0=Short	–
Fuel Trim Learned	1=On/0=Off	–
Fan 1	1=On/0=Off	–
Fan 2	1=On/0=Off	–

**Engine Data Display 04 Selected by 2: Data Display 1: Engine Data 2.2L
Automatic Transmission**

Parameter	Scaling	Value
Engine Speed	rpm=N/4	± 100 rpm from the Desired rpm
Desired Idle	rpm=N*12.5	ECM Idle Command
Engine Coolant Temperature	Celsius=n–40	85° – 115° C (185° – 239° F)
Intake Air Temperature	Celsius=n–40	10° – 80° C (50° – 176° F)
Throttle Position	%=n/2.56	0% (up to 100% at wide open throttle)

1F – 6 ENGINE CONTROLS

Parameter	Scaling	Value
Throttle Position	Volts= $n/51$	0.200–0.900v (up to 5.0 at wide open throttle)
MAP	kPa= N	23–35 kPa
BARO	kPa= $(n+28)/2.71$	65–100 kPa (varies with altitude and with the BARO pressure)
EGR Actual Position	%= $n/2.56$	0%
EGR Desired Position	%= $n/2.56$	0–100%
EGR Feedback	Volt= $5n/255$	
IAC Position	Counts= N	5–60
Cam Speed Activity	Counts= N	0–255
Ignition Voltage	Volts= $n/10$	12.0–15.0
Engine Run Time	Seconds= N	00:00:00–18:12:15 (hours:minutes:seconds)
BPW Bank 1	ms= $N/65.535$	0–999.9
Air Fuel Ratio	x:1= $n/10$	0:1–25.5:1
Spark	Degrees= $(n/2)–64$	64 to –64
Knock Retard	Degrees= $N/(256/22.5)$	0–90
Knock Active Counter	Counts= N	0–255
Knock Present	1=Yes/0=No	0–90
Calculated Load	%= $N/2.56$	0–100
Vehicle Speed	mph= $n/1.61$	0–255 mph
Air Condition Pressure	Volt= $5n/255$	0–5 volts
Oxygen Bank 1 Sensor 1	mv= $N/0.2304$	0–1132 mV
Oxygen Bank 1 Sensor 2	mV= $N/0.2304$	0–1132 mV
Decel Fuel Mode	1=On/0=Off	–
Power Enrichment Mode	1=Yes/0=No	–
Closed Loop	1=Yes/0=No	–
Loop Status	See Table 3	–
Hot Loop Open	1=Yes/0=No	–
Rich/Lean Bank 1	1=Rich/0=Lean	–
Short Term Fuel Trim	%= $(N–128)/1.28$	–100 to 100%
Long Term Fuel Trim	%= $(N–128)/1.28$	–100 to 100%
EVAP Purge Solenoid	%= $N/2.56$	0–100%
EVAP Vent Solenoid	1=On/0=Off	–
IAC Base Position	Counts= N	0–255
Fuel Trim Cell	Cell= N	
Calculated Air Flow	g/sec= $N/128$	0–512 g/sec
Weak Cylinder	Misfire Detected/Misfire Not DT	–
Rough Road Sensor	Volt= $5n/255$	0–5 volts
5 Volt Reference	Volt= $5n/255$	0–5 volts
Throttle at Idle	1=Yes/0=No	–
Power Steering Cramp	1=Yes/0=No	–
Air Conditioning Request	1=On/0=Off	–

Parameter	Scaling	Value
Air Conditioning Clutch	1=On/0=Off	–
Fuel Pump	1=On/0=Off	–
Malfunction Indicator Lamp	1=On/0=Off	–
Upshift Lamp	1=On/0=Off	–
Low Fuel Lamp	1=On/0=Off	–
Hot Open Loop Lamp	1=On/0=Off	–
Variable Gate Intake	1=Long/0=Short	–
Fuel Trim Learned	1=Yes/0=No	–
Fan 1	1=On/0=Off	–
Fan 2	1=On/0=Off	–
Park/Neutral	1=Yes/0=No	–

**EVAP Data Display 01 Selected by 2: Data Display 2: Specific Data 1: EVAP
Manual Transmission**

Parameter	Scaling	Value
Engine Speed	rpm=N/4	±100 rpm from the Desired rpm
Ignition Voltage	Volts=n/10	12.0–15.0
Engine Coolant Temperature	Celsius=n–40	85° – 115° C (39° – 93° F)
Start Up Coolant Temperature	Celsius=n–40	4° – 34° C (39° – 93° F)
Intake Air Temperature	Celsius=n–40	10° – 80
Start Up Intake Air Temperature	Celsius=n–40	12° – 42° C (54° – 108° F)
Engine Run Time	Seconds=N	00:00:00–18:12:15 (hours:minutes:seconds)
Fuel Level Sensor	Volt=5n/255	0.4–4.5 volts
Fuel Gauge	1=On/0=Off	–
EVAP Purge Solenoid	%=N/2.56	0–100%
EVAP Vent Solenoid	1=On/0=Off	–
EVAP Tank Vacuum	in H2O=(n(25/65535))–7.5	
Throttle Position	%=n/2.56	0% (up to 100% at wide open throttle)
Throttle Position	Volts=n/51	0.200–0.900v (up to 5.0 at wide open throttle)
IAC Position	Counts=N	5–60
BPW Bank 1	ms=N/65.535	0–999.9
Air Fuel Ratio	x:1=n/10	0:1–25.5:1
Spark	Degrees=(n/2)–64	64 to –64
MAP	kPa=N	25–35 kPa
BARO	kPa=(n+28)/2.71	65–100 kPa (varies with altitude and with the BARO pressure)
Calculated Load	%=N/2.56	0–100
Vehicle Speed	mph=n/1.61	0–255
Oxygen Sensor Bank 1 Sensor 1	mV=N/0.2304	0–1132
Oxygen Sensor Bank 1 Sensor 2	mV=N/0.2304	0–1132

**EVAP Data Display 02 Selected by 2: Data Display 2: Specific Data 1: EVAP
Automatic Transmission**

Parameter	Scaling	Value
Engine Speed	$\text{rpm}=\text{N}/4$	± 100 rpm from the Desired rpm
Ignition Voltage	$\text{Volts}=\text{n}/10$	12.0–15.0
Engine Coolant Temperature	$\text{Celsius}=\text{n}-40$	4°– 34°C (–39°– 93°F)
Start Up Coolant Temperature	$\text{Celsius}=\text{n}-40$	10° – 80
Intake Air Temperature	$\text{Celsius}=\text{n}-40$	12°– 42°C (54°– 108°F)
Start Up Intake Air Temperature	$\text{Celsius}=\text{n}-40$	–34.6°– 275°F (–37°– 135°C)
Engine Run Time	$\text{Seconds}=\text{N}$	Varies (since start up)
Fuel Level Sensor	$\text{Volt}=5\text{n}/255$	0.4–4.5 volts
Fuel Gauge	1=On/0=Off	–
Park/Neutral	1=Yes/0=No	–
EVAP Purge Solenoid	$\%=\text{N}/2.56$	0–100%
EVAP Vent Solenoid	1=On/0=Off	–
EVAP Tank Vacuum	$\text{in H}_2\text{O}=\text{n}(25/65535)-7.5$	
Fuel Tank Vacuum Sensor	$\text{Volt}=5\text{n}/255$	0.0–5.0
Throttle Position	$\%=\text{n}/2.56$	0% (up to 100% at wide open throttle)
Throttle Position	$\text{Volts}=\text{n}/51$	0.200–0.900v (up to 5.0 at wide open throttle)
IAC Position	$\text{Counts}=\text{N}$	5–60
BPW Bank 1	$\text{ms}=\text{N}/65.535$	0–999.9
Air Fuel Ratio	$\text{x}:1=\text{n}/10$	0:1–25.5:1
Spark	$\text{Degrees}=(\text{n}/2)-64$	64 to –64
MAP	$\text{kPa}=\text{N}$	12–103 kPa
BARO	$\text{kPa}=(\text{n}+28)/2.71$	65–100 kPa (varies with altitude and with the BARO pressure)
Calculated Load	$\%=\text{N}/2.56$	0–100
Vehicle Speed	$\text{mph}=\text{n}/1.61$	0–255
Oxygen Sensor Bank 1 Sensor 1	$\text{mV}=\text{N}/0.2304$	0–1132
Oxygen Sensor Bank 1 Sensor 2	$\text{mV}=\text{N}/0.2304$	0–1132

**EVAP Service Bay Test F5: Functional Tests–F5: Outputs–F5: EVAP Service Bay
Test All**

Parameter	Scaling	Value
EVAP Service Bay Test State	see PID table 4	–
EVAP Service Bay Test Min. TPS	%=N/2.56	0–100
Throttle Position	%=n/2.56	0–100
EVAP Service Bay Test Max. TPS	%=n/2.56	0–100
EVAP Service Bay Test Abort Reason	see PID table 5	–
EVAP Service Bay Test Results	see PID table 6	–
EVAP Purge Solenoid	%=N/2.56	0–100
EVAP Vent Solenoid	1=On/0=Off	–
EVAP Tank Vacuum	in H2O= $n(25/65535)-7.5$	
Fuel Tank Vacuum Sensor	Volt= $5n/255$	0.0–5.0
Engine Speed	rpm=N/4	± 100 rpm from the Desired rpm
Ignition Voltage	Volts= $n/10$	12.0–15.0
Engine Coolant Temperature	Celsius= $n-40$	85° – 115
Start Up Coolant Temperature	Celsius= $n-40$	4° – 34°C (39° – 93°F)
Intake Air Temperature	Celsius= $n-40$	10° – 80°C (50° – 176°F)
Start Up Intake Air Temperature	Celsius= $n-40$	12° – 42°C (54° – 108°F)
Engine Run Time	Seconds=N	00:00:00–18:12:15 (hours:minutes:seconds)
Fuel Level Sensor	Volt= $5n/255$	0.4–4.5
Fuel Gauge	1=On/0=Off	–

**EGR Data Display Selected by 2: Data Display 2: Specific Data 2: EGR All
Displays EGR01**

Parameter	Scaling	Value
Engine Speed	rpm=N/4	± 100 rpm from the Desired rpm
Ignition Voltage	Volts=n/10	12.0–15.0
IAC Position	Counts=N	0–255
Engine Coolant Temperature	Celsius=n–40	85° – 115° C (185° – 239° F)
Throttle Position	%=n/2.56	0% (up to 100% at wide open throttle)
Throttle Position	Volts=n/51	0.200–0.900v (up to 5.0 at wide open throttle)
EGR Actual Position	%=n/2.56	0%
EGR Desired Position	%=n/2.56	0–100%
EGR Feedback	Volt=5n/255	
EGR Closed Pintle Position	Counts=N	
EGR Trip Sample Count	Tests=N	
EGR EWMA Threshold	n=Counts(signed)	
EGR EWMA	Counts=n(signed)	
EGR Pintle Position Error	Counts=n(signed)	
Engine Run Time	Seconds=N	00:00:00–18:12:15 (hours:minutes:seconds)
BPW Bank 1	ms=N/65.535	0–999.9
Air Fuel Ratio	x:1=n/10	0:1–25.2:1
Spark	Degrees=(n/2)–64	64 to –64
MAP	kPa=N	25–35 kPa
BARO	kPa=(n+28)/2.71	65–100 kPa (varies with altitude and with the BARO pressure)
Calculated Load	%=N/2.56	0–100
Vehicle Speed	mph=n/1.61	0–255

**Oxygen Sensor Data Display Selected by F2: Data Display F2: Specific Data F4:
Oxygen Sensors All Displays O2SO1**

Parameter	Scaling	Value
Engine Speed	rpm=N/4	± 100 rpm from the Desired rpm
Engine Run Time	N=seconds	00:00:00–18:12:15 (hours:minutes:seconds)
Loop Status	0=Open/1=Closed	–
O2S 1 Bank 1 Sensor 1	mV=N/0.2304	0–1132 mV
O2S 1 Bank 1 Sensor 1	0=Not Ready, 1=Ready	–
Rich/Lean Bank 1	0=Lean, 1=Rich	–
Injector Pulse Bank 1	msec=N/65.535	
Start Up Coolant Temperature	Celsius=n–40	4°– 34°C (39°– 93°F)
Engine Coolant Temperature	Celsius=n–40	85°– 115°C (185°– 239°F)
Start Up Intake Air Temperature	Celsius=n–40	12°– 42°C (54°– 108°F)
Intake Air Temperature	Celsius=n–40	10°– 80°C (50°– 176°F)
O2S 1 Time to Activity Bank 1 Sensor 1	Seconds=N	
Short Term FT Bank 1	%=(N–128)1.28	–100 to 100%
Long Term FT Bank 1	%=(N–128)1.28	–100 to 100%
TP Angle	%=N/2.56	0–100%
Calculated Air Flow	g/sec=n/128	0–512 g/sec
MAP	kPa=n	25–35 kPa
EVAP Purge PWM	%=N/2.56	0–100%
Ignition 1	Volts=N/10	12.0–15.0
Air Fuel Ratio	x:1=N/10	0:1–25.5:1
Decel Fuel Mode	0=Inactive, 1=Active	–
Power Enrichment	0=Inactive, 1=Active	–
HO2S 2 Warm Up Time Bank 1 Sensor 1	Seconds=N	
HO2S 2 Bank 1 Sensor 2	mV=N/0.2304	0–1132

**Misfire Data Display Selected by F2: Data Display F2: Specific Data F5: Misfire
All 2.2L Displays MISF01**

Parameter	Scaling	Value
Misfire Current #1	Count=n	0-255
Misfire History #1	Count=n	0-255
Misfire Current #2	Count=n	0-255
Misfire History #2	Count=n	0-255
Misfire Current #3	Count=n	0-255
Misfire History #3	Count=n	0-255
Misfire Current #4	Count=n	0-255
Misfire History #4	Count=n	0-255
Misfire Failures Since First Fail	N=decimal	
Misfire Passes Since First Fail	N=decimal	
Total Misfire Current Count	Count=n	0-255
Weak Cylinder	See Table 01	-
Engine Speed	rpm=N/4	± 100 rpm from the Desired rpm
TP Angle	%=N/2.56	0-100
Calculated Load	%=N/2.56	0-100
Engine Coolant Temperature	Celsius=n-40	85° – 115° C (185° – 239° F)
Intake Air Temperature	Celsius=n-40	10° – 80° C (50° – 176° F)
Cam Active Counter	Counts=N	0-255
Spark	Degrees=(n/2)-64	64 to -64
G Sensor	Volts=n/51	
EGR Desired Position	%=n/2.56	0-100%
EGR Actual Position	%=n/2.56	0%
MAP	kPa=N	25-35 kPa
Vehicle Speed	mph=n/1.61	0-255 mph
Air Conditioning Request	1=On/0=Off	-
Air Conditioning Clutch	1=On/0=Off	-
Knock Active Counter	Counts=N	0-255
Knock Retard	Degrees=N/(256/22.5)	0-90°
Decel Fuel Mode	1=Yes/0=No	-
Power Enrichment Mode	1=Yes/0=No	-
Injector Pulse Bank 1	msec=N/65.535	
O2S 1 Bank 1 Sensor 1	mv=N/0.2304	0-1132
HO2S 2 Bank 2 Sensor 1	mv=N/0.2304	0-1132
Short Term FT Bank 1	%=(N-128)1.28	-100 to 100
Long Term FT Bank 1	%=(N-128)1.28	-100 to 100

TEC Display Table Selected by 5: Engine Outputs 5: Engine Outputs TEC01

Parameter	Scaling	Value
Engine Speed	rpm=N/4	±100 rpm from the Desired rpm
TP Angle	%=N/2.56	0–100%
Engine Coolant Temperature	Celsius=n–40	85°– 115° C (185°– 239° F)
Intake Air Temperature	Celsius=n–40	10°– 80° C (50°– 176° F)
Cam Activity Counter	N=decimal	0–255
Spark	Degrees=(n/2)–64	64 to –64
MAP	kPa=N	12–103 kPa
Vehicle Speed	mph=n/1.61	0–255 mph
Decel Fuel Mode	1=Yes/0=No	–
Power Enrichment Mode	1=Yes/0=No	–
Injector Pulse Bank 1	msec=N/65.535	
Crank Error Latched	1=Yes/0=No	–
Sum Out Of Range	1=Yes/0=No	–
Opposing Factor Out Of Range	1=Yes/0=No	–
Factor Out Of Range	1=Yes/0=No	–
Enable Criteria Not Met	1=Yes/0=No	–
Cat Damaging Misfire	1=Yes/0=No	–
Test is Running	1=Yes/0=No	–
Learned This Key Cycle	1=Yes/0=No	–
Attempts to Learn	Counts=N	

ENGINE DATA DISPLAY TABLE DEFINITIONS

ECM Data Description

The following information will assist in diagnosing emission or driveability problems. A first technician can view the displays while the vehicle is being driven by second technician. Refer to Powertrain On-Board Diagnostic (OBD II) System Check for additional information.

A/C Clutch

The A/C Relay represents the commanded state of the A/C clutch control relay. The A/C clutch should be engaged when the scan tool displays ON.

A/C Pressure

The A/C High Side displays the pressure value of the A/C refrigerant pressure sensor. The A/C High Side helps to diagnose the diagnostic trouble code (DTC) P0533.

A/C Request

The A/C Request represents whether the air conditioning is being requested from the HVAC selector. The input is received by the instrument panel cluster and then sent over

Universal Asynchronous Receiver Transmitter (UART) serial data to the ECM and finally to the scan tool over class 2 serial data.

Air Fuel Ratio

The Air Fuel Ratio indicates the air to fuel ratio based on the Oxygen Sensor (O2S 1) inputs. The ECM uses the fuel trims to adjust fueling in order to attempt to maintain an air fuel ratio of 14.7:1.

BARO

The Barometric Pressure (BARO) sensor measures the change in the intake manifold pressure which results from altitude changes. This value is updated at ignition ON and also at Wide Open Throttle (WOT).

BPW Bank 1

Indicates the base Pulse Width Modulation (PWM) or ON time of the indicated cylinder injector in milliseconds. When the engine load is increased, the injector pulse width will increase.

Calculated Air Flow

The calculated air flow is a calculation based on manifold absolute pressure. The calculation is used in several diagnostics to determine when to run the diagnostics.

Camshaft Activity Counter

The Camshaft Position (CMP) activity counter displays the activity sent to the ECM from the CMP sensor. The counter will continually increment while the engine is running. The CMP activity counter is helpful in diagnosing DTC P0342.

Desired Idle

The ECM commands the idle speed. The ECM compensates for various engine loads in order to maintain the desired idle speed. The actual engine speed should remain close to the desired idle under the various engine loads with the engine idling.

Engine Coolant Temperature

The Engine Coolant Temperature (ECT) sensor sends engine temperature information to the ECM. The ECM supplies 5 volts to the engine coolant temperature sensor circuit. The sensor is a thermistor which changes internal resistance as temperature changes. When the sensor is cold (internal resistance high), the ECM monitors a high voltage which it interprets as a cold engine. As the sensor warms (internal resistance decreases), the voltage signal will decrease and the ECM will interpret the lower voltage as a warm engine.

EGR Desired Position

The desired Exhaust Gas Recirculation (EGR) position is the commanded EGR position. The ECM calculates the desired EGR position. The higher the percentage, the longer the ECM is commanding the EGR valve ON.

Engine Run Time

The engine run time is a measure of how long the engine has been running. When the engine stops running, the timer resets to zero.

Engine Speed

Engine Speed is computed by the ECM from the fuel control reference input. It should remain close to desired idle under the various engine loads with the engine idling.

EVAP Purge

The Evaporative Emission (EVAP) purge valve solenoid is a proportional signal used in order to control the EVAP canister purge function. At 0% the valve is commanded fully closed. 100% implies that the valve is fully open.

EVAP Purge Solenoid

When energized, the EVAP Solenoid allows the fuel vapor to flow from the EVAP canister to the engine. The EVAP Solenoid is normally closed. The EVAP Solenoid is pulse width modulated by the ECM. The EVAP Solenoid reads 0% when closed and 100% when fully opened.

EVAP Vent Solenoid

The EVAP Vent Solenoid allows fresh outside air to the EVAP canister during purge mode. The EVAP Vent Solenoid allows the diagnostic to pull a vacuum on the fuel tank by closing the vent solenoid.

Fan

The Fan Control (FC) Relay is commanded by the ECM. The FC Relay displays the command as ON or OFF.

Fuel Level Sensor

The Fuel Level Sensor monitors the fuel level in the tank. The Fuel Level Sensor monitors the rate of change of the air pressure in the EVAP system. Several of the Enhanced EVAP System diagnostics are dependent upon the correct fuel level.

Fuel Tank Pressure Sensor

The fuel tank pressure sensor measures the difference between the pressure or the vacuum in the fuel tank and the outside air pressure. When the air pressure in the fuel tank equals the outside air pressure, the output voltage of the sensor is 1.3 to 1.7 volts.

IAC Position

The scan tool displays the ECM command for the Idle Air Control (IAC) pintle position in counts. The higher the number of counts, the greater the commanded idle speed reads. The Idle Air Control responds to changes in the engine load in order to maintain the desired idle rpm.

Intake Air Temperature

The ECM converts the resistance of the Intake Air Temperature (IAT) sensor to degrees in the same manner as the engine coolant temperature (ECT) sensor. Intake air temperature is used by the ECM to adjust fuel delivery and spark timing according to incoming air density.

Ignition 1 (Voltage)

The ignition volts represent the system voltage measured by the ECM at the ignition feed circuit.

Knock Retard

The Knock Sensor (KS) Retard indicates the amount of spark advance the ECM is decreasing in response to the KS signal.

Knock Present

The KS Noise Channel indicates when the ECM detects the KS signal. The ECM should display NO at idle.

Calculated Load

Indicates engine load based on manifold absolute pressure. The higher the percentage, the more load the engine is under.

Long Term FT

The Long Term Fuel Trim (FT) is derived from the short term fuel trim value. The Long Term FT is used for the long term correction of the fuel delivery. A value of 128 counts

(0%) indicates that the fuel delivery requires no compensation in order to maintain a 14.7:1 air to fuel ratio. A value below 128 counts means that the fuel system is too rich and the fuel delivery is being reduced. The ECM is decreasing the injector pulse width. A value above 128 counts indicates that a lean condition exists for which the ECM is compensating.

Long Term FT Average

Long Term FT Average is derived from the long term fuel trim from all of the cells. The ECM then takes all of the values and then creates one average value.

Loop Status

The Closed Loop is displayed indicating that the ECM is controlling the fuel delivery according to the Oxygen Sensor (O2S 1) voltage as close to an air/fuel ratio of 14.7 to 1 as possible.

MAP

The Manifold Absolute Pressure (MAP) sensor measures the change in the intake manifold pressure which results from engine load and speed changes. As the intake manifold pressure increases, the air density in the intake also increases and the additional fuel is required.

Misfire Current #1–4

Indicates the number of current misfires that are present in the indicated cylinder. Increments only when misfire is current.

Misfire History #1–4

Indicates the number of misfires that have occurred after 195 current misfires have been counted. The current misfire counter will add its misfires to the history misfire counter after 195 total misfires have taken place. If 1 cylinder is misfiring, the misfiring current counter will have 195 misfires counted before adding to its history counter. If 2 cylinders are misfiring, the misfiring current counter will add to their history counters after 97 misfires. The counter increments only after a misfire diagnostic trouble code (DTC) has been set.

Oxygen Sensor Bank 1 Sensor 1

The pre-converter Oxygen Sensor (O2S 1) reading represents the exhaust oxygen sensor output voltage. This voltage will fluctuate constantly between 100 mv (lean exhaust) and 900 mv (rich exhaust) when the system is operating in a Closed Loop.

Oxygen Sensor Bank 1 Sensor 2

The post-converter Heated Oxygen Sensor (HO2S 2) represents the exhaust oxygen output voltage past the catalytic converter. This voltage remains inactive, or the

voltage will appear lazy within a range of 100 mv (lean exhaust) and 900 mv (rich exhaust) when operating in a Closed Loop.

Short Term FT

The Short Term FT represents a short term correction to fuel delivery by the ECM in response to the amount of time the oxygen sensor voltage spends above or below the 450 mv threshold. If the oxygen sensor has mainly been below 450 mv, indicating a lean air/fuel mixture, short term fuel trim will increase to tell the ECM to add fuel. If the oxygen sensor voltage stays mainly above the threshold, the ECM will reduce fuel delivery to compensate for the indicated rich condition.

Short Term FT Average

The Short Term FT Average is derived from the short term fuel trim from all of the cells. The ECM takes all of the values and then creates one average value.

Spark

This is a display of the spark advance Ignition Coil calculation which the ECM is programming in the ignition system. It computes the desired spark advance using data such as engine temperature, rpm, engine load, vehicle speed and operating mode.

TCC Brake Switch

When the brake pedal is applied, the Torque Converter Clutch (TCC) brake switch sends a signal to the PCM/ECM to disengage the TCC and disable the cruise control.

Total Misfire Current Counter

Indicates the total number of misfires that have been detected in all the cylinders after 100 engine cycles. One cycle equals one complete 4 stroke cycle. The total misfire only increments during the steady state cruise conditions.

TP Angle

From the Throttle Position (TP) Sensor voltage input, the ECM computes the TP. The TP Angle will auto zero to 0% at idle (TP voltage below 0.90 volt). The TP Angle will read 100% at WOT.

TP Sensor

The ECM uses the TP Sensor in order to determine the amount of the throttle demanded by the vehicle's operator. The TP Sensor reads between 0.36–0.96 volts at idle to above 4 volts at WOT.

Vehicle Speed

The vehicle speed sensor signal is converted into mph or km/h for display. The vehicle speed output from the ECM is 4000 pulses per mile. The scan tool uses the class 2 serial data from the ECM to obtain vehicle speed, while the Instrument Panel Cluster (IPC), cruise control module and the chime alarm module use the 4000 ppm output.

FASTENER TIGHTENING SPECIFICATIONS

Application	N•m	Lb–Ft	Lb–In
Accessory Mounting Bracket Bolts	35	26	–
Camshaft Position Bolts	12	–	106
Crankshaft Position Sensor Retaining Bolt	10	–	89
Electronic Ignition System Ignition Coil Retaining Bolts	10	–	89
Engine Coolant Temperature Sensor	25	18	–
Evaporative Emission Canister Flange Bolt	20	15	–
Evaporative Emission Canister Protective Cover	8	–	71
Evaporative Emission Canister Purge Solenoid Bracket Bolts	5	–	44
Exhaust Gas Recirculation Valve Retaining Bolts	20	15	–
Fuel Cutoff Switch Bolts	3	–	27
Fuel Pressure Regulator Retaining Clamp	12	–	106
Fuel Rail Retaining Bolts	25	18	–
Fuel Tank Strap Retaining Nuts	13	–	115
Heated Oxygen Sensor	41	30	–
Idle Air Control Valve Retaining Bolts	3	–	27
Knock Sensor Bolt	20	15	–
Manifold Absolute Pressure Sensor Retaining Bolt	10	–	89
Oxygen Sensor	41	30	–
Rear A/C Compressor Mounting Bracket Bolts	35	26	–
Throttle Body Retaining Nuts	9	–	80
Throttle Cable Bracket Bolts	10	–	89
Throttle Position Sensor Retaining Bolts	2	–	18

FUEL SYSTEM SPECIFICATIONS

Gasoline

All engines are designed to use unleaded fuel only. Unleaded fuel must be used for proper emission control system operation. Its use will also minimize spark plug fouling and extend engine oil life. Using leaded fuel can damage the emission warranty coverage. The fuel should meet specification ASTM D4814 for the U.S. or CGSB 3.5 M93 for Canada. All engines are designed to use unleaded fuel with a minimum U(R+M)/2e (pump) octane number of 87, where R=research octane number, and M=motor octane number.

Ethanol

You may use fuel containing ethanol (ethyl alcohol) or grain alcohol providing that there is no more than 10 percent ethyl alcohol by volume.

Methanol

Do not use fuels containing methanol. Methanol can corrode metal parts and cause damage to plastic and rubber parts in the fuel system.

Methyl Tertiary–Butyl Ether (MTBE)

You may use fuel containing Methyl Tertiary–Butyl Ether (MTBE) providing there is no more than 15 percent MTBE by volume.

TEMPERATURE VS RESISTANCE

°C	°F	OHMS
Temperature vs Resistance Values (Approximate)		
100	212	177
90	194	241
80	176	332
70	158	467
60	140	667
50	122	973
45	113	1188
40	104	1459
35	95	1802
30	86	2238
25	77	2796
20	68	3520
15	59	4450
10	50	5670
5	41	7280
0	32	9420
–5	23	12300
–10	14	16180
–15	5	21450
–20	–4	28680
–30	–22	52700
–40	–40	100700